

Mazak

Yamazaki Mazak Vertical Machining Centre

VCN Smooth series made in Japan

kitagawa

LEERING
SINCE 1939 HENGLO

▼ Dedicated



NC ROTARY TABLE



WISE





**NC ROTARY
TABLE**

NC Rotary Table Machine Compatibility

NC ROTARY TABLE

Mazak

Kitagawa

Machine Model Rotary Table		VCN-430A/430A HS	VCN-530C/530C HS	VCN-535C	VCN-700D
					
MK 	200	○P3	○P5	○P7	○
	250	△(○) Note 2)	○P5	○P7	○P9
CK 	160	○P3	○	○	○
RK 	200	△(○) Note 2)	○	○	○
TMX 	160	○P4	○	○	○
	200	△(○) Note 2)	○	○	○
	250	△	○P6	○	○
TRX 	320	△	△	○P8	○
TP 	430	△	△	○	○P9
	530	—	—	△	△P10
RKT 	180	△	△	○	○
TT 	200	△	△P6	○P8	○
	251	△	△	○	○
	321	—	△	△	○P10

Note 1) "△" indicates that it can be installed conditionally.



Note 2) (○) is HS type compatibility.

Note 3) The confirmation of interference with machining centres is based on the latest data held by Kitagawa at the time of catalogue creation, but for more accuracy, please confirm them with the actual machine data.





Yamazaki Mazak Machining Centre VCN-430A/430A HS

MK200RAM



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.
The parenthesized dimensions indicate the dimensions for VCN-430A HS.



CK160RM



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.
The parenthesized dimensions indicate the dimensions for VCN-430A HS.



TMX 160BM



Caution



Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.
The parenthesized dimensions indicate the dimensions for VCN-430A HS.



Yamazaki Mazak Machining Centre

VCN-530C/530C HS



MK200RAM



Caution

Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.
Note that the reference groove is not in the center of the machine table.

MK250RAM





Caution

Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.
Note that the reference groove is not in the center of the machine table.





■ TMX250BM



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.

■ TT200BM-02




Caution The ★ mark on the Y stroke is limited by 95 mm.
Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.



Yamazaki Mazak Machining Centre


VCN-535C

MK200RAM



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.




MK250RAM



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.






TRX320BM



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.


TT200BM-02



Caution Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.




MK250RAM





Caution

Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.




TP430RHM





Caution

Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.







TP530RHM



Caution

The ★ mark on the Y stroke is limited by 15 mm.
Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.

■ TT321BMM



Caution



Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.



Mazak **kitagawa**

NC ROTARY TABLE

TP530RHM



Caution The ★ mark on the Y stroke is limited by 15 mm.
Check the interference between the splash guard and the cable.
Check the interference of the tool when ATC is operating.

TT321BMM

